

TESY HL200 Portable Fan Heater

User Instructions



Thank you for purchasing this Tesy heating appliance. These instructions provide you with the correct information for the safe and efficient operation of this appliance. Please read these instructions carefully before using and always keep them for future reference. Failure to adhere to these instructions may cause damage to the unit, property or persons.

Voltage: 230V
Frequency: 50Hz
Power: 1000/2000W

IMPORTANT

- Before using the appliance, check the voltage of the mains power supply corresponds to the voltage specified on the label of the appliance.
- The appliance is fitted with a 13 amp fused plug.
- This product meets the requirements of European directive 89/336 concerning electromagnetic compatibility.

FUNCTIONS AND USAGE

- **Cooling mode (fan only):** Turn the switch clockwise to position "  ".
- **Heating at low power (1000W):** Turn the switch clockwise to position "I".
- **Heating at high power (2000W):** Turn the switch clockwise to position "II".
- **Temperature regulation:** When the desired room temperature is reached, turn the switch slowly clockwise after position "II" until you hear a click. The set temperature is managed and maintained automatically via the thermostat.
- **Switch off:** Turn the switch clockwise to position "0".
- **Anti frost prevention function:** When the thermostat is at position "  ", the appliance sustains minimum room temperature of about 5 °C with a minimum consumption of power.

MAINTENANCE

Before cleaning the appliance, always disconnect from the mains power.

The fan heater should be checked and if required cleaned at least once every two weeks. We recommend an air blower or vacuum that can blow for cleaning your appliance. This should preferably be done outside.

- 1.) Using the air or vacuum, blow through the appliance from the front air grille.
- 2.) Vacuum any dust or other deposits from the air inlet opening (over the fan motor), and the outlet grille.
- 3.) Clean any deposits or marks from the appliance's exterior case with a damp soft cloth.
- 4.) Do not use abrasive cleaning detergents or solvents.

IMPORTANT NOTES

- Never use the fan heater in a bathroom or in an area containing baths, showers, washbasins, in swimming pool areas, or close to any other water or wet items

- Do not use the device to dry laundry. Never cover the air inlet and outlet apertures as this will cause the appliance to over heat!
- The minimum distance between the fan heater and pieces of furniture or other objects should be at least 50 cm.
- In the event the power supply cable has to be replaced, this must be carried out by a competent person or electrician.
- The fan heater should not be placed in direct proximity to an electric socket or directly below it.
- The appliance should not be used in rooms or areas, of less than 4 m² (40sq.ft) floor area.
- If the appliance appears to be faulty, do not attempt to use it. A faulty or damaged appliance should be immediately unplugged from the mains power.
- In the event the appliance does not work, always check the fuse first.
- When not in use, unplug the appliance from the mains power.
- Ensure that the cable does not touch the metal grill in front of the hot air outlet, when the appliance is in use.
- Do not wind the cable around the heater when it is in use.

Important:

To prevent fire, do not cover the heater when working. The convector heater is provided with a protection device, which will switch it off should it overheat. For the appliance to resume normal working, switch it off and wait for several minutes to cool down. After checking the inlets and outlets for blockages, and/or eliminating the cause for overheating, plug the appliance into the main and try again. If it does not work it should be inspected by a qualified electrical engineer.

Attention: In order to prevent overheating, do not cover the heater!

GUARANTEE

This appliance is guaranteed for one year from the date of purchase. If any defects arise due to faulty materials or workmanship, the unit will either be replaced or repaired free of charge. The appliance should be returned to the dealer or outlet where it was purchased with the original invoice or receipt as proof of purchase.

The guarantee is subject to the following provisions

- 1) The guarantee is only valid in the country of purchase
- 2) The product must be correctly used and operated in accordance with these instructions.
- 3) It must solely be used for domestic applications.
- 4) The guarantee will be rendered invalid if the product is resold or has been damaged or modified by unauthorized persons.
- 5) The manufacturer/distributor disclaims any liability for incidental or consequential damages
- 6) This guarantee is in addition to, and does not diminish your statutory or legal rights